

**Hand pump for easy injection of Stopaq FN 2100****Application**

- Compact, easy-to-use hand pump
- The 620 gr Stopaq FN 2100 cartridge fits the pump perfectly

**Properties**

- Easy to use.
- No need for electricity on site.
- No need to pour product.
- No product loss.
- Comes with several accessories for application in tight spaces or behind cables.

**Directions**

- Open the cartridge gun by unscrewing the front cap.
- Remove the cap from the Stopaq FN 2100 cartridge.
- Slide the cartridge into the gun.
- Screw the front cap back on the gun to close it.
- Use a long nozzle or other accessory if required.
- Pump manually to apply the product.
- Important note: put the cartridges in water at 30°C beforehand for an easy application.

**Pictures**



### **Packaging**

Per piece

Contents: cartridge gun, long nozzle, 4 short nozzles, elbow, cleaning brush, putty knife, coupling connector.

### **Safety information – Transport – Handling and storage - Waste**

Consult the most recent and product-related safety information sheet from Rewah in compliance with the (EU) 453/2010 annex II/A guidelines. The information on the abovementioned safety information sheet has been drawn up with the greatest care and is based on the knowledge available at the date of issue. We accept no liability for damage or hindrance of any kind which could be caused by the use of the product concerned.

### **Considerations**

The data included in this sheet, the application advices and other recommendations are based on extensive research and experience. They are however not binding also in relation to third party liability. They do not protect the customer against checking the products and directions for their suitability for the purpose. The characteristics and properties described are average values and analyses registered at 20°C, variances are tolerated. Our customer service will gladly answer your questions. The rewrite of this sheet replaces all previous sheets.